

## M6S6 Fan Connection Demo

1. Aura Sync ARGB header link to motherboard Addressable ARGB port on the motherboard.

2. how to extend fans? 5V3pin ARGB header link additional 3pin male of fan and Female fan link to Motherboard Addressable ARGB port on the motherboard, (under extension mode, it is available for Aura SYNC only, ie, RGB light mode via software controlled, and build-in manual mode disable).

### FAN CABLES CONNECTION INSTRUCTIONS

